App guide · Windows 10 and 11

AKJ Control

One app for every AKJ device. Settings are saved on the device itself, so the app can stay closed. No account, works offline.

> AKJ Control is a concept, like the brand. There is no installer: the guide walks through every screen.

AKJ is a fictional concept brand, made as a portfolio project. AKJ Control is a concept too.

The main screen

VECTOR 8K



1. Open AKJ Control. The mouse appears under Devices as soon as it is connected.
2. Under Performance, set up to five sensitivity stages, the polling rate and the lift-off distance.
3. Under Buttons, change what the side buttons and the wheel do.
4. Every change is saved to the mouse, in the profile you picked. Close the app; the settings stay.

Firmware 1.4.2

Saved on the device

Up to five profiles per device. Close the app and they stay.

Firmware in the app

Updates install from AKJ Control; each device's support page has the steps.

No account

Works offline. Nothing is sent about how you play.

AKJ is a fictional concept brand, made as a portfolio project. AKJ Control is a concept too.

Every device, one app

SHIFT 75



1. Open AKJ Control and pick SHIFT 75 under Devices.
2. On a FLUX HE board, set how deep each key fires, from 0.1 to 4.0 mm, and turn on rapid trigger for the keys you play with.
3. Remap any key, and choose what the volume dial does.
4. Changes are saved to one of the keyboard's four profiles.

Firmware 2.1.0

AKJ is a fictional concept brand, made as a portfolio project. AKJ Control is a concept too.

Every device, one app

WAVE and WAVE BASE



1. Open AKJ Control; WAVE and WAVE BASE show up together.
2. Under Sound, shape the 10-band EQ. It is saved on the BASE, so it stays without the app.
3. Set the game / chat mix and how much of your own voice you hear.
4. Turn the lighting off for the full 70 hours on 2.4 GHz.

Firmware 3.0.4

AKJ is a fictional concept brand, made as a portfolio project. AKJ Control is a concept too.

Every device, one app

AXIS



1. Open AKJ Control and pick AXIS.
2. Shape the stick response and set the dead zone. Calibrate the Hall-effect sticks if they ever drift.
3. Map the four rear paddles to any input.
4. The app shows which trigger stop is set; flip the stop switches on the back to change it.

Firmware 1.2.3

AKJ is a fictional concept brand, made as a portfolio project. AKJ Control is a concept too.

Every device, one app

COMMAND



1. Open AKJ Control and pick COMMAND.
2. Remap any of the 21 keys and set how deep each one fires, from 0.1 to 4.0 mm.
3. Choose whether the thumbstick moves like W A S D keys or like a joystick.
4. Link it with SHIFT 75, so both change profile together.

Firmware 1.0.6

AKJ is a fictional concept brand, made as a portfolio project. AKJ Control is a concept too.

Keeping devices up to date

Firmware

In AKJ Control (recommended)

1. Connect the device: most with their cable, WAVE through its BASE.
2. Open AKJ Control, pick the device, then Firmware → Update.
3. Keep it connected until the app says it's done, one to four minutes.

Without the app

1. Each device's support page has a standalone updater to download.
2. Its README.txt says how to connect that device and what happens next.
3. Concept: the ZIP holds the release notes and the steps, not a program.

Help for each device, its connection steps and its release notes are on the AKJ site, under Support.

AKJ is a fictional concept brand, made as a portfolio project. AKJ Control is a concept too.